CONCORD LIMA



DEUTSCH	01
ENGLISH	11
FRANÇAIS	21
ESPAÑOL	31
ITALIANO	41
PORTUGUÊS	51
NEDERLANDS	61
NORSK	71
DANSK	81
SUOMI	91

Norm / standard / norme / norma EN 16120:2012+A1:2014



 \bigcirc







ENGLISH

THANK YOU!	11
OVERVIEW	12
SAFETY INFORMATION!	13
FOLDING AND UNFOLDING THE CONCORD LIMA	14
USING THE SECURING STRAPS	15
ATTACHING AND REMOVING THE TRAY	16
USING THE SEAT BELTS	17
CLEANING THE COVER	19
CONCORD ORIGINAL SPARE PARTS/ACCESSORIES	19
GUARANTEE	20

_ THANK YOU!

Thank you for choosing a quality product from CONCORD. The versatility and safety of this product will impress you. We hope you will have lots of fun with your new CONCORD LIMA.

_ **IMPORTANT!** PLEASE KEEP FOR FUTURE REFERENCE.





_SAFETY INFORMATION!

IMPORTANT!

- Read these instructions carefully before use and keep them for future reference. Your child's safety may be affected if you do not follow these instructions.
- Keep these instructions for future reference.



WARNING!

- Never leave your child unattended.
- Always use the restraint system and ensure it is correctly fitted.
- Always use the chair attachment system and ensure it is correctly fitted before use.
- Always check the security and the stability of the chair mounted seat on the adult chair before use.
- Do not use this chair mounted seat on stools or benches.
- This product is intended for children able to sit up unaided and up to 3 years or a maximum weight of 15 kg.
- Ensure that the adult chair with the chair mounted seat is placed in a position where the child is not able to use its feet to push against the table or any other structure as this can cause the tip over of the adult chair supporting the chair mounted seat.
- Do not use the chair mounted seat if any part is broken, torn or missing.
- Do not use accessories or replacement parts other than those approved by the manufacturer.
- The CONCORD LIMA should be installed on a chair, only by an adult.
- Take care that the chair on which you wish to secure the CONCORD LIMA is stable and securely positioned on a level surface.

_ FOLDING AND UNFOLDING THE CONCORD LIMA

The CONCORD LIMA folds and unfolds like a deckchair. When unfolding, take care that the central joint clicks audibly into place.

To fold the CONCORD LIMA, first remove the tray (06) from the chair (see ATTACHING AND REMOVING THE TRAY). Then release the lock (07) on the bottom of the seat area. The CONCORD LIMA can then simply be folded together.

_ USING THE SECURING STRAPS

To secure the CONCORD LIMA to a chair, use the securing straps (02) provided. Check that the chair is standing firmly and securely on a level floor. Feed each of the two securing belts around both the backrest and the seat of the chair on which you wish to secure the CONCORD LIMA. Adjust the straps by sliding the belt buckle to the required length and fasten the belt locks.

CAUTION!

- Take care that all fastenings click audibly into place, that the fastenings are not lying across (chair) edges, and that the CONCORD LIMA is secured safely and does not wobble.
- For safety reasons, all the straps on the CONCORD LIMA are not just tightened, but have to be adjusted by sliding the belt buckle on the belt to the correct length.







_ ATTACHING AND REMOVING THE TRAY

To attach the tray to the CONCORD LIMA, first release the press studs on the seat cover (04) and undo the Velcro fastener that is on the backrest cover (01). Next fold back the backrest cushion. Now position the tray on the backrest and ensure that it engages. Finally, secure the backrest cover over the attached tray.

CAUTION!

• When used with the tray, it is essential that the tabs on the side of the seat cover pass over the side sections of the tray and are secured to the side press studs.



To remove the tray, first fold back the backrest cushion and undo the press studs on the side tabs of the seat cover. Then release the lock (05) on the back of the backrest and pull the tray upwards and away from the backrest.

If you wish to use the CONCORD LIMA without the tray, secure the side tabs of the seat cover using the press studs on the back of the backrest.

USING THE SEAT BELTS



Feed the centre strap with the buckle through between the child's legs. Then insert the buckle adaptors on the lap straps from above into the top of the buckle. They should audibly click into position.



To open the harness system, press the button in the middle of the buckle until the buckle adaptors are released.



CAUTION!

• Always use the restraint system and ensure it is correctly fitted.

Adjust the straps so that they are taut and lie close against the child.

To adjust the strap length, slide the belt clasps upwards or downwards. Check that the straps are not twisted.



The childproof lock is on the back of the buckle. This can be activated and deactivated by turning. Activating the childproof lock blocks the buckle opening mechanism.



CAUTION!

- Always use the restraint system and ensure it is correctly fitted.
- Always use the lap straps together with the centre strap.

_ CLEANING THE COVER

The cover on the CONCORD LIMA can be removed and washed in a washing machine. To remove the cover you need to release the press studs and unthread the seat belts.

When replacing the cover, first thread the seat belts through the relevant openings in the seat cover and then fasten the press studs.



Wash separately, warm wash (30°) – do not bleach or iron, tumble or spin dry, not suitable for dry cleaning!

_ CONCORD ORIGINAL SPARE PARTS/ACCESSORIES

Information on CONCORD original spare parts/accessories is available at your retailer's or directly from CONCORD.

Concord GmbH Industriestraße 25 95346 Stadtsteinach Germany

Phone +49 (0)9225.9550-0 Fax +49 (0)9225.9550-55 info@concord.de

www.concord.de

_ GUARANTEE

The guarantee begins on the day of purchase. The guarantee period corresponds to the statutory warranty period in the end-user's country concerned. At the manufacturer's discretion, the guarantee shall cover rectification, replacement or a price reduction.

The guarantee is valid for the original purchaser only. In the event of any defect, claims can not be considered unless the specialist dealer is notified of the fault as soon as it occurs for the first time. If the specialist dealer is unable to remedy the problem himself, he must return the product to the manufacturers together with details of the complaint, official proof of purchase and the purchase date.

The manufacturers assume no liability for faulty goods that they did not supply.

The guarantee does not apply where:

- the product has been modified;
- the product is not brought back to the specialist dealer complete with proof of purchase within 14 days of the defect occurring;
- the defect was caused by improper usage or maintenance or due to anything else deemed to be the fault of the user, in particular failure to comply with the instructions for use;
- repairs have been carried out on the product by third parties;
- the defect was caused as the result of an accident.
- the serial number has been damaged or removed

The guarantee makes no provision for any alteration or deterioration to the product that is incurred through normal usage (wear and tear). The period of guarantee shall not be extended by any remedial measures carried out by the manufacturers in the event of a claim.

- _ DEUTSCH
- _ ENGLISH
- _ FRANÇAIS
- _ ESPAÑOL
- _ ITALIANO
- _ PORTUGUÊS
- _ NEDERLANDS
- _ NORSK
- _ DANSK
- _ SUOMI

Einbau- und Bedienungsanleitung Instructions for attachment and use Directives d'installation et mode d'emploi Instrucciones de montaje y de uso Istruzioni per l'uso e il montaggio Manual de montagem e de utilização Inbouw- en bedieningshandleiding Bruksanvisning og monteringsveiledning Monterings- og betjeningsveiledning Kiinnitys- ja käyttöohjeet

Concord GmbH Industriestraße 25 95346 Stadtsteinach Germany

Phone +49 (0)9225.9550-0 Fax +49 (0)9225.9550-55 info@concord.de

www.concord.de

